

COCKPIT PREPARATION	
GEAR PINS and COVERS	REMOVED
FUEL QUANTITY	___ KG
SEAT BELTS SIGN	ON
ADIRS	NAV
BARO REF	(BOTH) QNH/QFE

BEFORE START	
PARKING BRAKE	as REQ
TAKEOFF SPEED & THRUST	(BOTH)
WINDOWS	CLOSED
BEACON	ON

AFTER START	
ANTI ICE	as REQ
ECAM STATUS	CHECKED
PITCH TRIM	SET
RUDDER TRIM	NEUTRAL

TAXI	
FLIGHT CONTROLS	CHECKED
FLAPS	(BOTH) SET
RADAR & PRED WS	ON & AUTO
ENGINE MODE SEL	as REQ
ECAM MEMO	T.O. NO BLUE
<ul style="list-style-type: none"> - AUTO BRAKE MAX - SIGNS ON - CABIN READY - SPLRS ARM - FLAPS TO - TO CONFIG NORM 	

LINE-UP	
T.O. RWY	BOTH
TCAS	TA or TA/RA
PACKS 1+2	ON

DEPARTURE CHANGE	
RWY& SID	
FLAP SETTING	(BOTH) CONF
T.O. SPEED & THRUST	(BOH) CONG
FCT ALT	SET

APPROACH	
BARO REF	(BOTH) SET
SEAT BELT SIGNS	ON
MINIMUM	SET
AUTO BREAK	SET as REQ
ENG MODE SEL	as REQ

LANDING	
ECAM MEMO	LDG. NO BLUE
<ul style="list-style-type: none"> - LDG GEAR DOWN - SIGNS ON - CABIN READY - SPLRS ARM - FLAPS SET 	

AFTER LANDING	
RADAR & PRED WS	OFF

PARKING	
PARK BRK or CHOCKS	SET
ENGINES	OFF
WING LIGHTS	OFF
FUEL PUMPS	OFF

SECURNG	
OXYGEN	OFF
EMER EXIT LT	OFF
EFB's	OFF
BATTERIES	OFF

TAKEOFF CG/TRIM POS

